

ASSEMBLY INSTRUCTIONS

IMPORTANT: WE ADVISE YOU TO ASSEMBLE THE GAZEBO ONCE BEFORE GOING CAMPING TO ASSURE THAT ALL PARTS ARE PRESENT AND TO BECOME FAMILIAR WITH THE ASSEMBLY OF THE GAZEBO.


Two people are recommended for assembly of this gazebo.

Step 1 - Lay Out the Gazebo

Select a level, smooth site for your gazebo. Remove all the parts from the bag.


Step 2 - Extend the Frame

Take the folded frame and place it in the center of your site. Each person should grasp legs that are diagonally opposite and pull backwards to extend the frame.



Make sure the frame is fully extended.

Slide the lock **A** on the leg upward until it snaps into place. See below.



Make sure the joints on the center roof support poles are straightened and snapped into place.

Step 3 - Install the Roof

Drape the fabric roof over the frame, stretching the corners of the roof over the corners of the frame.



The roof will be taut after you stretch the roof fully over the frame.

Duck under the roof and fasten the velcro straps **B** attached to the roof around the frame. (or, if you are tall, you can do this step after Step 4!)

Step 4 - Raise the Gazebo

Pull up on the leg sections until the push button snaps into place, locking the legs.

If conditions warrant, drive stakes through the holes in the feet of the leg poles to secure the gazebo.

Step 5 - Install the Guylines

In windy conditions you will want to install the guy lines provided. Tie the loose end of each guy line through the webbing loops **C** on the corners of the gazebo.

Make a loop at the other end of a guy line with the slider. Stake it out about 3' from the base of the gazebo and adjust the tension of the line with the slider **D**. Repeat for the other guy lines.

