




ASSEMBLE MANUAL FOR SF4001




①




②



③




O



1PC

P




1PC

H



1PC

I



1PC


J



M6*40mm

4PCS

C



M6*35mm

4PCS

E








1PC


Q



8PCS




1PC




1PC



1PC




1PC




M6*40mm

4PCS




M6*35mm

4PCS



M6*45mm


1PC




1PC




9PCS




①



N




②




1PC

B



J

M6*40mm



4PCS

D

M6*15mm



4PCS

E



1PC

Q



8PCS

2PCS